



忘记笔记本BIOS密码，清除BIOS密码

第一步：笔记本启动的过程按F2键，进入输入BIOS 密码的界面，输入三次错误密码，就会显示下图



选择第一个Enter Unlock Password.



第二步：记录Key后面的8个数字（我的是94148751），用手机进入下面的网站：<https://bios-pw.org/>

BIOS Password Recovery for Laptops

Quick and easy way to recover BIOS passwords on laptops. Based on research by Dogbert and Asyncritus.

Enter your code

Get password

Try one of the following codes:

| | |
|---------------------------|----------|
| InsydeH20 BIOS (Acer, HP) | 21820397 |
| Fujitsu-Siemens | 86883503 |


* FOR SOME DELL CODES PRESS CTRL-ENTER, NOT ENTER, WHEN ENTRING CODE INTO THE BIOS

| Vendor | Type | Hash Code/Serial example |
|--------|------------------|--------------------------|
| mpaq | 5 decimal digits | 12345 |
| l | serial number | 1234567-595B |
| | | 1234567-D35B |
| | | 1234567-2A7B |
| | | 1234567-1D3B |
| | | 1234567-1F66 |
| | | 1234567-6FF1 |


https://blog.csdn.net/qq_40301550

在输入框 里输入Key后面的8个数字（我的是94148751），点击Get password,得到8个数字（我的是21820397）。

第三步：在下面输入框（第二行就是输入框）得到的8个数字



进入到BIOS界面



第一行显示，我设置了超级用户密码

选择第四行 设置超级用户密码，按Enter键进入蓝色小窗口，在第一行Enter current password 输入框输入第二步得到的8个数字，剩下的两行不要填，保存，再次进入BIOS就不会有输入密码的提示了。